
**FIG.** 1






FIG. 3
Workstation Software Architecture




FIG. 4




FIG. 5





FIG. 6



#### Normal Sign On Message Sequence




FIG. 8

#### Normal Sign Off Message Sequence






FIG. 9


### HeadSet Unjack Logoff Message Sequence




#### Inbound Call Message Sequence




# FIG. 11 Sample Dial Number Dialog




#### **Outbound Message Sequence**




#### Call Hold and Unhold Message Sequence




#### Call Transfer to Outside Number



#### Call Conference with Supervisor



# Operator Hangup with DisconnectCall Key Message Sequence



# FIG. 17 PlusTapi Utility Mode Panel

·	PlusTcp conversation number for telephony support (1-8)
	TCP/IP address of telephony support (or "LocalHost")
	TCP/IP port number of telephony support
	Timeout for initialization of telephony support (seconds)
	Timeout for establishing telephony connection (seconds)
	Timeout for allowing operator to replug headset (seconds)
	TCP/IP address of Call Director Custom Server
	TCP/IP address of Voice Over Data Custom Server

# Sample InfoWin Utility Settings for CSW

Field1-	-Field4Field5-	-Field3-	-Field11-	-Field9-
Field2-	-Field6Field7-	-Field13-	Field12-	-Field10-

# Sample CSW Running in Normal Mode

	HOMES TOOK HOUSE	Transport of the second of the	5.7
Mine.	Called 987-654-3210	Microphone: 50	2
Mula	eaneu. (98/2009-3210)	。	



